ADJUSTABLE FLUID RESISTANCE






How the Patented Twin Tank Works

LEVEL ONE - MINIMUM




LEVEL TEN - MAXIMUM



ACTIVE RESISTANCE Fluid in the outer tank

ADJUSTMENT LEVER

Fluid in the inner tank PASSIVE HOLDING



LOW RESISTANCE

Low level of fluid in the Active Resistance Tank & High level in the Passive Holding Tank



HIGH RESISTANCE

High level of fluid in the Active Resistance Tank & Low level in the Passive Holding Tank